



For all kinds of music

Hello!

Y887

Outdoor Portable Bluetooth Speaker

User Manual

Dear AWEI User,
Thank you for choosing AWEI product. Your choice is crucial for us, which means AWEI has added a new user. Hope that we will bring you a good experience through our products and services. Also hope you will put forward the good advice and suggestions by official customer hotline, Weibo and Wechat in the process of product experience, which can help AWEI to constantly improve product and service.

If you encounter any problems in the using product, please refer to service process. Your support is our strongest power, also your recognition and evaluation are a great encouragement to AWEI. Thank you!

AWEI sales team

Introduction

Thank you very much for using the AWEI Y887 Outdoor Portable Bluetooth Speaker, please read this manual in detail before using this product.

Bluetooth wireless communications Technology introduction



Bluetooth is a kind of wireless technology which support short distance communications (work normally within a distance of 10M) with it you can exchange information by wireless between many IT digital devices like mobile phones / wireless earphones / computers etc. Bluetooth technology effectively and simplify to the communications which makes device and data transmission quickly and off effectively.

Accessories List

1X Bluetooth Speaker 1X User Manual
1X USB Charging Cable



Overview Of Speaker



Key description

- Power on button
1.1. Before using wireless pairing, first turn on the audio power, it is already the default wireless model.
- Pause/play key
Click: Play/Pause
Long press: Exit/reconnect Bluetooth connection
Double click in Bluetooth mode to call back; Click: answer/end
In case of a call, long press for 2 seconds to reject the call
In radio mode, click: mute Long press: receive music experience.
- Lamp button
Click: Convert light mode
Long press: Turn lights on/off
- Serial key
Click: Tandem/Exit Tandem
Long Press: Convert Mode
- +key
Click: Volume up
Long press: next song
- key
Click: Volume Down
Long press: Previous song
- Type-C jack
1. Charging line interface. When the Type-C charging line is inserted, the device is charged by default
2. When using the radio function, you need to plug in the charging line as the radio antenna, The radio function can be used normally
- TF jack
When the TF card is inserted, the default is the TF card playing mode
- USB connector
When the USB stick is inserted, it defaults to USB playback mode
- AUX jack
Standard Φ 3.5mm headphone jack, which defaults to AUX playback mode when plugged in

How To Use

- Wireless pairing
1.1. Before using wireless pairing, first turn on the audio power, it is already the default wireless model.
1.2. Turn on the wireless device, search for AWEI Y887, connect and pair, connect After success, start playing music experience.
- Suitable for various mobile phone accessories wireless technology, wireless adapter, wireless player.
- Voice prompt
3.1. There is a voice prompt when turning on/off;
3.2. When the volume is increased to the maximum volume, there will be a voice prompt, and the minimum volume will not have a voice prompt.
- 3.3 Shut down after detecting 3.4V low power prompt 3 times;
- Mode switching
4.1. It enters wireless mode by default when power on. Mode switching sequence: wireless mode - FM mode - TF card mode - U disk mode - AUX mode
4.2. Mode: Post-insertion priority.
- Play indicator:
Wireless search status: white light flashes quickly, about 0.5 seconds/time;
Wireless pairing status: white light is always on
Playing status: the white light flashes slowly about 1 second/time;
- Power 30%, the first one is normally on, the second one and the third one flashes power 40%, the first and second lamps on, and the third one is flashing power 100% all lamps flash
- Volume
Turn on the default speaker volume at 70%.

How To Use

- Charging and using:
This device has a built-in overcharge protection circuit, which can be connected to a computer or charger for a long time, about four hours Charging is complete.
The play time of each battery will vary depending on the volume used rather different.
- If there is no working state, it will automatically shut down after 15 minutes.

Troubleshooting:

- Automatic shutdown: When the battery power is low, the battery protection will be turned on automatically, please charge it for 4 hours before use.
- Unable to play music: The music file storage path cannot be recognized by the player. Please store the music file in the root directory of the removable device.
- There is no sound when connected to the computer: the computer interface is connected incorrectly, please select the correct audio output port
- There is no response to the keys or the function is disordered: try again after shutting down.
- When the machine is abnormal, use a slender round bar to press the reset button in the AUX hole switch reset

Specifications

Bluetooth Version: V5.3
Input Mode: Bluetooth- AUX- TF Card- U Disk- FM
Speaker Full Range Unit: 66mm 4 Ω
Speaker Power: 10W x 2
Charging Voltage: 5V/1A
Frequency Response: 80Hz-15KHz
Battery Capacity: 3600mAh / 3.7V
Working Time: about 5 hours
Charging Time: about 4 hours
Bluetooth Transmission Distance: 10M

Safety And Maintenance

Please read suggests below in order to helping prolong the product lifespan and clearly understand the warranty clauses.

- ★ Keep the product dry, do not put it in humid circumstance to avoid short circuit.
- ★ Do not expose it to the sun or high heat. High heating will short lifespan of electronic components, damage battery and deform some plastic parts.
- ★ Do not put it in cold circumstance to avoid damage to PCB board.
- ★ Do not attempt to take apart the product, especially non-professionals.
- ★ Do not fall, vibrate strongly, strike with hard objects, to avoid damage to inner electronic circuit.
- ★ Do not use high chemical products, detergent to clean the item.
- ★ Do not scratch the surface with sharp items to avert damaging the case and appearance.
- ★ Do not make it charging 10 hours continuously for the sake of lifespan.

If the product can not work properly, please send it to AWEI authorized maintenance agents. Our staff will help to solve the problems for you.

Statement: In order to improve product performance we will upgrade products, the content may change without notice, pls forgive! Thank you for your purchase.

Supervised by H.K. Yale International Co., Ltd
Produced by Shenzhen Yale Electronics Co., Ltd
Factory Add: 4th Floor, Buiding 2, Yujingtai Industrial Park, Huaxing Road, Longhua District, Shenzhen, China.

Customer service hotline/ Fax:
Tel: +86-755-82999998
Fax: +86-755-83777998
Cooperation mailbox: yale@awei.hk
After-sales service: service@awei.hk

For more information please visit:
www.aweistore.com



AWEI WeChat

Contact:
twitter : <https://www.twitter.com/aweiearphone>
facebook : <https://www.facebook.com/aweiproducs>
instagram : <http://www.instagram.com/aweiearphone>

Products after-sales service

1. 7 Days Refund Policy

A. Guarantee of Refund: Within 7 days since the date of purchase, the manufacturer promises to refund if the product bought from AWEI immediate shops or authorized distributor shops is in quality problem (artificial and external force damage excluded).

B. Refund Procedure: Please take the product, whole set of package and original invoice to (or please freight pre-paid to) the shop you bought the product for checking. The seller will check by Quality Assurance Identification Rules to clarify the problem. If yes, the seller should refund the money the user paid for the product.

2. 15 Days Replacement Policy

A. Guarantee of Replacement: Within 15 days since the date of purchase, the manufacturer promises to replace if the product bought from AWEI immediate shops or authorized distributor shops is in quality problem (artificial and external force damage excluded).

B. Replacement Procedure: Please take the product, whole set of package and original invoice to (or please freight pre-paid to) the shop you bought the product for checking. The seller will check by Quality Assurance Identification Rules to clarify the problem. If yes, the seller should replace the product and issue a new invoice to the user. Freight arrangements please check with the shop you contact.

3. Twelve Months Warranty Policy

A. Guarantee of Maintenance: Within twelve months since the date of purchase, the manufacturer promises to offer

Products after-sales service

maintenance service if the product bought from AWEI immediate shops or authorized distributor shops is in quality problem (artificial and external force damage excluded).

B. Maintenance Procedure: Please take the product, whole set of package and original invoice to (or please freight pre-paid to) the shop you bought the product for checking. The seller will check by Quality Assurance Identification Rules to clarify the problem. If yes, the seller should fill warranty card with official stamp and send back to manufacturer. After repairing, manufacturer sends the product to the seller and the seller should inform the user to collect it. Freight arrangements please check with the shop you contact.

4. Quality Assurance Identification Rules

A. Quality Assurance is NOT applicable to those items: accessories like packing box, pouch, ear clip and earmuffs; product beyond warranty period; product got from unauthorized agents or informal channels; fake AWEI product; AWEI premium; artificial damaged product; external force damaged product.

B. Quality Assurance Identification Procedure: Check warranty period (by original invoice) — confirm original product (check security code on AWEI official website) — check product damage (clarity artificial damage and external force like water, fire, chemicals or weight crush damages) — check product quality (to confirm if the testing result is conform to description) — check buying channel (subject to manufacturer's verification).

AWEI Warranty Card (please fill this carefully)

Model No.		Barcode	
User Name		TEL	
Address			
Seller		Seller Tel	
Seller Add			
Date of purchase		Date for Maintenance	
Damage situation		Maintenance time	
Remark			