版本	变更描述	变更日期	设计师
A01	初始发行	2024.09.24	王海芳

裁切线 辅助线
压痕线 牙 刀
V槽线 画 线
半穿刀

■ 外表面视图 □ 内表面视图

128铜版纸/风琴折 展开尺寸：900x100mm 实际尺寸：100x100mm

awei用维®
For all kinds of music

KT18
户外K歌无线音箱

用户手册

尊敬的AWEI用户：
感谢您选用AWEI产品！您的选择对于我们至关重要，这意味着AWEI又增加了一名新用户。希望通过我们的产品和服务，为您带来上佳的体验。也希望您在产品体验过程中，通过官方客户热线、微博、微信、等提出好的意见和建议，帮助AWEI不断完善产品和服务。

如果您在产品使用过程中遇到任何问题，请参照服务流程，方便、快捷地获取帮助。您的支持是我们成长的动力，您的每一次认可和评价都是对AWEI莫大的鼓励。谢谢！

AWEI营销团队

非常感谢您使用AWEI KT18户外K歌无线音箱，在使用本产品之前，请详细阅读本手册。

附件清单

1X 蓝牙音箱+背带 1X USB-C充电线 1X 遥控器 2X 麦克风 1X 3.5mm音频线 1X 说明书

产品说明图

① 开机/关机
② 模式切换/断开蓝牙/恢复出厂设置
③ 麦克风
④ EQ切换/关闭省电/静音
⑤ 灯效切换
⑥ 播放/暂停
⑦ 减音量/上一曲
⑧ 加音量/下一曲
⑨ MIC端口
⑩ 耳机端口
⑪ AUX端口
⑫ USB端口/TF卡
⑬ Type-C充电口

开机：短按"⏻"键1秒，如插有U盘、TF卡、Line-in 开机音箱记忆进入上一次工作模式。不插U盘、TF卡、Line-in开机音箱自动进入蓝牙模式搜索状态。
关机：开机状态下，长按"⏻"键2秒，关闭蓝牙音箱。
模式切换：短按一下"M"键可以切换BT//TF/AUX/USB等工作模式。
强制断开蓝牙：在蓝牙连接状态下，长按"M"键3秒可以断开蓝牙连接。
恢复出厂设置：蓝牙状态下，长按"M"键8秒可以恢复出厂设置，清除之前的操作记忆。
麦克风：按一下"🎤"键，开启麦克风，指示灯闪烁，麦克风连接后指示灯会长亮；再按一下话筒键关闭麦克风功能。
EQ切换：开机默认EQ为全频，短按一下"EQ"键为3D，再短按一下为重低音。
关闭省电：开机状态下，长按"EQ"键8秒音箱关闭省电模式，此时可以长时间给其他电子设备提供5V最大1A的电流。

1

怎样使用

静音：长按"EQ"键1.5秒音箱开启外放静音功能，此时音箱无声，监听接口插入耳机是有声的。
灯效切换：开机默认呼吸按一下"☼"键，切换律动再按关灯。
TWS：双击"M"键，音箱进入TWS状态。
播放/暂停：在蓝牙/TF播放状态下短按一下"▷"键，暂停播放。
在AUX播放状态下短按一下"▷"键，播放静音。

来电接听： 有电话呼入短按一下"▷"键，可以接听电话	🎤 — **话筒音量-** 按住"🎤"键，再按"—"键，话筒音量减小，共10级
来电拒接： 长按2秒"▷"键，拒接电话	🎤 + **话筒音量+** 按住"🎤"键，再按"+"键，话筒音量增加，共10级
结束通话： 通话中短按一下"▷"键可以挂断电话	EQ — **混响-** 按住"EQ"键，再按"—"键，混响减小，共10级
尾号重拨： 连接手机，双击"▷"键可以重拨最后拨打的电话	EQ + **混响+** 按住"EQ"键，再按"+"键，混响增加，共10级
语音助手： 长按"▷"3秒启动语音助手功能	
减音量： 短按"—"键，音量减小	☼ — **外接麦克风音量-** 按住"☼"键，再按"—"键，外接有线麦克风减小，共10级
上一曲： 长按"—"键，切换到上一首歌曲	
加音量： 短按"+"键，音量增大	☼ + **外接麦克风音量+** 按住"☼"键，再按"+"键，外接有线麦克风增加，共10级
下一曲： 长按"+"键，切换到下一首歌曲	

▌无线配对
1.请将蓝牙机器和手机(或其他的连接设备)的距离在12米的范围内；
2.确保机器在开机状态蓝灯快闪，此时进入蓝牙待连接状态，等待连接；
3.开启用户手机蓝牙功能(或其他蓝牙设备)，并进行搜索或扫描，此时手机会搜索到附近所有的蓝牙设备，点选搜索到的机器名称"AWEI KT18"成功配对连接后，机器指示灯长亮，表示配对连接成功；

2

怎样使用

▌智能省电
音箱10分钟未连接会自动关机，连接后不自动关机。(有提示声)
▌低电报警功能
20%电量时低电报警，10%以下音箱启动关机程序关机。(有提示音)
▌USB供电
开机状态下，长按"EQ"键8秒音箱关闭省电模式，插入USB充电线可以长时间给外部设备进行应急充电，输出电压DC5V最大电流为1A。
▌AUX 音频播放
插入3.5mm音频线，自动播放AUX提供的音乐
▌USB播放
插入U盘自动播放U盘音乐
▌TF卡播放
插入卡自动播放TF卡音乐

▌LED指示灯状态
1)开机：蓝灯闪烁，RGB灯效默认为律动；关机：LED灯全熄灭；
2)蓝牙连接后播放、暂停蓝灯长亮；
3)TF卡、U盘、AUX播放蓝灯长亮，暂停蓝灯慢闪；
4)开机EQ默认为全频，白灯亮为3D、绿灯亮为重低音音效；
5)启动TWS功能时，黄灯闪烁，TWS配对成功后主、副机黄灯长亮；连接手机后主机黄灯、蓝灯长亮，副机黄灯长亮蓝灯熄灭。
6)麦克风指示灯蓝灯闪烁为麦克风启动，连接麦克风后蓝灯长亮；
7)充电红灯亮，充满电红灯灭，低电提醒红闪烁。

3

产品规格

蓝牙版本：Bluetooth 5.3
支持协议：A2DP v1.3/ AVRCP v1.6/HFP v1.7/HID v1.1 /AVCTP v1.4/AVDTP v1.3/and SPP v1.2
电池容量：8000mAh
播放时间：≥8小时(50%音量)
充电时间：≤8-10小时
频率响应范围：40HZ-18KHZ
蓝牙有效距离：≥12米
充电输入标准：TYPE-C 5V/3A
最大功率：120W
产品尺寸：300mm*110.4*184.8mm

安全与保养

在使用时，请阅读以下建议有助于您遵守保修条款，并延长产品的使用寿命。
★ 保持产品干燥，勿将产品放在潮湿的地方，以免影响产品内部电路；
★ 不要将产品放置在太阳晒射或者高温的地方，高温会缩短电子部件的使用寿命损坏电池，使某些塑料部件变形；
★ 不要将产品放在过冷的地方，以免损坏内部电路板；
★ 不要试图拆开产品，尤其是非专业人员，可能会损坏产品；
★ 不要跌落、强烈震动、用硬体撞击产品，以免损坏内部电路；

4

安全与保养

★ 不要使用烈性化学制品、清洁剂清洁机器；
★ 不要用尖体在产品表面上乱划，以免损坏外壳和影响外观；
★ 不要对机器连续充电超过10小时，以免影响使用寿命；

如产品不能正常工作，请将其送至AWEI的授权维修机构，工作人员会热心帮您解决问题。
声明：为提高产品性能我们会进行产品升级，本说明内容可能会有所变更，恕不另行通知，敬请见谅。感谢您的选购！

香港雅乐国际有限公司 监制
深圳市雅乐电子有限公司 出品
厂址：中国深圳市龙华区大浪裕景泰科技工业园

消费者服务热线/传真：
服务热线：400-998-3899
合作邮箱：yale@awei.hk
售后服务：service@awei.hk

获取更多信息请访问：
www.awei.hk

国外社区：
twitter : https://www.twitter.com/Aweiglobal
facebook : https://www.facebook.com/aweiproducts
instagram : https://www.instagram.com/awei_official

官方微信查真伪

5

产品售后服务指南

一、七天包退细则
A. 包退原则：用户在AWEI直属专营店或经AWEI授权的分销店所购买的产品，自购买之日起7天内，产品未受到任何人为或外力的损害而发生的产品质量问题，厂家包退货。
B.退货流程：用户将产品、包装和票据完整地拿到(或自费邮寄到)购买地点给卖家检测——卖家按质保鉴定规则检测，鉴定该产品实属产品质量问题——卖家退还用户购买产品时所付的费用。
二、十五天包换细则
A. 包换原则：用户在AWEI直属专营店或经AWEI授权的分销店所购买的产品，自购买之日起15天内，产品未受到任何人为或外力的损害而发生的产品质量问题，厂家包换货。
B. 换货流程：用户将产品、包装和票据完整地拿到(或自费邮寄到)购买地点给卖家检测——卖家按质保鉴定规则检测，鉴定该产品实有产品质量问题——卖家为用户更换货品并开具新票据。
三、十二个月包修细则
A. 包修原则：用户在AWEI直属专营店或经AWEI授权的分销店所购买的产品，自购买之日起十二个月内，产品未受到任何人为或外力的损害而发生的产品质量问题，厂家包修。
B. 包修流程：用户将产品、包装和票据完整地拿到(或自费邮寄到)购买地点给卖家检测——卖家按质保鉴定规则检测，鉴定该产品有产品质量问题——卖家填写产品质保卡并盖公章——卖家将产品邮寄给厂家维修——厂家维修好邮寄给卖家——卖家通知用户取货。
四、质保鉴定规则
A. 无质保产品：包装盒、收纳袋、耳机夹、耳套等附属部件；不在三包期内的产品；非AWEI授权 或非正规渠道所购买的产品；非AWEI正品；赠品；被人为损害的产品；被外力损害的产品。
B. 质保鉴定：查三包期(以票据为证)——查正品(进AWEI官方网站查防伪编码)——查产品损坏情况(有无明显人为造成的破损、有无被水、火、化学物品或重物损害的痕迹)——查产品质量(在符合产品使用的情况下测试效果是否与产品描述相符)——查购买渠道(限厂家查证)

6

AWEI产品保修卡(请认真填写完整)

产品型号		条形码	
用户名字		用户电话	
用户住址			
商家名称		商家电话	
商家地址			
购买日期		报修日期	
损坏情况		维修时间	
备注			

awei®
For all kinds of music

KT18
Outdoor Karaoke Wireless Speaker

User Manual

Dear AWEI User,
Thank you for choosing AWEI product. Your choice is crucial for us,which means AWEI has added a new user. Hope that we will bring you a good experience through our products and services. Also hope you will put forward the good advice and suggestions by official customer hotline, Weibo and Wechat in the process of product experience,which can help AWEI to constantly improve product and service.

If you encounter any problems in the using product, please refer to service process. Your support is our strongest power, also your recognition and evaluation are a great encouragement to AWEI. Thank you!

AWEI sales team

Thank you very much for using the AWEI KT18 outdoor karaoke wireless speaker, please read this manual in detail before using this product.

Accessories List

1X Bluetooth speaker +shoulder strap 1X USB-C charging cable 1X remote control 2X microphones 1X 3.5mm audio cable 1X instruction manual

Overview Of Speaker

① Power on/off
② Mode switch/disconnect Bluetooth /restore factory settings
③ Microphone
④ EQ switch/Close power saving/mute
⑤ Lighting effect switching
⑥ Play / Pause
⑦ Volume down/previous song
⑧ Volume Increase /next song
⑨ MIC port
⑩ Headphone port
⑪ AUX port
⑫ USB port/TF card
⑬ Type-C charging port

Power on: Short press the "⏻" key for 1 second. If a USB flash drive, TF card, or Line-in is inserted, the speaker will enter the last working mode when powered on. If no USB flash drive, TF card, or Line-in is inserted, the speaker will automatically enter the Bluetooth mode search state.
Power off: In the powered-on state, long press the "⏻" key for 2 seconds to turn off the Bluetooth speaker.
Mode switch: Short press the "M" key to switch the working modes such as BT/U disk/TF/AUX.
Force disconnect Bluetooth: In the Bluetooth connection state, long press the "M" key for 3 seconds to disconnect the Bluetooth connection.
Restore factory settings: In the Bluetooth state, long press the "M" key for 8 seconds to restore the factory settings and clear the previous operation memory.

1

How To Use

Microphone: Press the "🎤" button to turn on the microphone, the indicator light flashes, and the indicator light will stay on after the microphone is connected; press the microphone button again to turn off the microphone function.
EQ switch: The default EQ at power on is full frequency, short press the "EQ" key for 3D, and short press again for heavy bass.
Turn off power saving: In the powered-on state, long press the "EQ" key for 8 seconds to turn off the power saving mode of the speaker. At this time, it can provide 5V maximum 1A current to other electronic devices for a long time.
Mute: Press and hold the "EQ" button for 3 seconds to turn on the external mute function. At this time, the speaker is silent, and there is sound when the headphones are plugged into the monitoring interface.
Lighting effect switching: Press the "☼" button to switch to the default breathing mode, and then press it to turn off the light.
TWS: Double-click the "M" button and the speaker enters TWS state.
Play/Pause: In Bluetooth/TF playback mode, short press the "▷" key to pause playback.
In AUX playback mode, short press the "▷" key to mute playback.

Answering a call: When there is an incoming call, short press the "▷" key to answer the call.	🎤 — **Microphone Volume -** Press and hold the "🎤" key, then press the "—" key to reduce the volume of the call. There are 10 levels in total.
Rejecting a call: Long press the "▷" key for 2 seconds to reject the call.	🎤 + **Microphone Volume +** Press and hold the "🎤" key, then press the "+" key to increase the volume of the voice message. There are 10 levels in total.
Ending a call: Short press the "▷" key to hang up the call during a call.	
Redialing the last number: Connect the phone to Bluetooth, double-click the "▷" key to redial the last call.	EQ — **Reverberation-** Press and hold the "EQ" key, then press the "—" key to reduce the reverberation, a total of 10 levels
Voice assistant: Long press "▷" for 3 seconds to start the voice assistant function	EQ + **Reverberation+** Press and hold the "EQ" key, then press the "+" key to increase the reverberation, a total of 10 levels
Volume reduction: Short press the "—" key to reduce the volume.	
Previous song: Long press the "—" key to switch to the previous song	☼ — **External Microphone Volume -** Press and hold the "☼" key, then press the "—" key to reduce the volume of the external wired microphone, a total of 10 levels
Volume increase: Short press the "+" key to increase the volume	
Next song: Long press the "+" key to switch to the next song	☼ + **External Microphone Volume +** Press and hold the "☼" key, then press the "+" key to add an external wired microphone, a total of 10 levels

2

How To Use

▌Wireless pairing
1. Please keep the Bluetooth machine and mobile phone (or other connected devices) within a range of 12 meters;
2. Make sure the blue light of the machine flashes quickly when it is turned on, and then enter the Bluetooth waiting state and wait for connection;
3. Turn on the Bluetooth function of the user's mobile phone (or other Bluetooth devices) and search or scan. At this time, the mobile phone will search for all nearby Bluetooth devices. Click the searched machine name "AWEI KT18" and successfully pair and connect. The machine indicator light is always on, indicating that the pairing connection is successful;
▌Intelligent power saving
The speaker will automatically shut down if it is not connected for 10 minutes, and will not shut down automatically after it is connected. (with a prompt sound)
▌Low power alarm function
When the power is 20%, the low power alarm will sound, and the speaker will start the shutdown program and shut down when the power is below 10%. (with a prompt sound)
▌USB power supply
When the speaker is turned on, long press the "EQ" button 8 seconds to turn off the power saving mode of the speaker. Inserting a USB charging cable can provide emergency charging for external devices for a long time. The output voltage is DC5V and the maximum current is 1A.
▌AUX audio playback
Insert a 3.5mm audio cable to automatically play the music provided by AUX
▌USB playback
Insert a USB flash drive and automatically play USB flash drive music
▌TF card playback
Insert a card and automatically play TF card music

▌LED indicator status
1) Power on: blue light flashes, RGB lighting effect defaults to rhythm; Power off: LED lights are all off;
2) After Bluetooth connection, the blue light stays on for playback and pause;
3) The blue light stays on for TF card, U disk, and AUX playback, and the blue light flashes slowly when paused;
4) The power-on EQ defaults to full frequency, the white light is on for 3D, and the green light is on for heavy bass sound effect;
5) When the TWS function is activated, the yellow light flashes, and the main and auxiliary units have yellow lights on after TWS pairing is successful; after connecting to the mobile phone, the main unit has yellow and blue lights on, and the auxiliary unit has yellow lights on and blue lights off.
6) The microphone indicator light flashes blue to start the microphone, and the blue light stays on after the microphone is connected;
7) The charging red light is on, the red light goes out when fully charged, and the low battery reminder red flashes.

3

Specifications

Bluetooth version: Bluetooth 5.3
Supporting protocols: A2DP v1.3/ AVRCP v1.6/HFP v1.7 /HID v1.1/AVCTP v1.4/AVDTP v1.3/and SPP v1.2
Built in battery: 8000mAh
Music time: ≥8 hours (50% volume)
Charging time: ≤8-10 hours
Frequency response range: 40HZ-18KHZ
Bluetooth effective distance: ≥12 meters
Charging input standard: TYPE-C 5V/3A
Maximum power: 120W
Product size: 300mm*110.4*184.8mm

Safety And Maintenance

Please read suggests below in order to helping prolong the product lifespan and clearly understand the warranty clauses.
★ Keep the product dry, do not put it in humid circumstance to avoid short circuit.
★ Do not expose it to the sun or high heat. High heating will short lifespan of electronic components, damage battery and deform some plastic parts.
★ Do not put it in cold circumstance to avoid damage to PCB board.
★ Do not attempt to take apart the product, especially non-professionals.
★ Do not fall, vibrate strongly,strike with hard objects, to avoid damage to inner electronic circuit.

4

Safety And Maintenance

★ Do not use high chemical products,detergent to clean the item.
★ Do not scratch the surface with sharp items to avert damaging the case and appearance.
★ Do not make it charging 10 hours continuously for the sake of lifespan.

If the product can not work properly, please send it to AWEI authorized maintenance agents. Our staff will help to solve the problems for you.

Statement: In order to improve product performance we will upgrade products, the content may change without notice,pls forgive! Thank you for your purchase.

Supervised by H.K. Yale International Co., ltd
Produced by Shenzhen Yale Electronics Co., ltd
Factory Add: 4th Floor, Buidling 2, Yujingtai Industrial Park, Huaxing Road, Longhua District, Shenzhen, China.

Customer service hotline/ Fax:
Hotline: 400-998-3899
Cooperation mailbox: yale@awei.hk
After-sales service: service@awei.hk

For more information please visit:
www.awei.hk

Contact:
twitter : https://www.twitter.com/Aweiglobal
facebook : https://www.facebook.com/aweiproducts
instagram : https://www.instagram.com/awei_official

AWEI WeChat

5

Products after-sales service

1. 7 Days Refund Policy
A. Guarantee of Refund: Within 7 days since the date of purchase, the manufacturer promises to refund if the product bought from AWEI immediate shops or authorized distributor shops is in quality problem (artifical and external force damage excluded).
B. Refund Procedure: Please take the product, whole set of package and original invoice to (or please freight pre-paid to) the shop you bought the product for checking. The seller will check by Quality AssuranceIdentification Rules to clarify the problem. If yes, the seller should refund the money the user paid for the product.

2. 15 Days Replacement Policy
A. Guarantee of Replacement: Within 15 days since the date of purchase, the manufacturer promises to replace if the product bought from AWEI immediate shops or authorized distributor shops is in quality problem (artifical and external force damage excluded).
B. Replacement Procedure: Please take the product, whole set of package and original invoice to (or please freight pre-paid to) the shop you bought the product for checking. The seller will check by Quality Assurance Identification Rules to clarify the problem. If yes, the seller should replace the product and issue a new invoice to the user. Freight arrangements please check with the shop you contact.

3. Twelve Months Warranty Policy
A. Guarantee of Maintenance: Within twelve months since the date of purchase, the manufacturer promises to offer maintenance service if the product bought from AWEI immediate shops or authorized distributor shops is in quality problem (artifical and external force damage excluded).
B. Maintenance Procedure: Please take the product, whole set of package and original invoice to (or please freight pre-paid to) the shop you bought the product for checking. The seller will check by Quality Assurance Identification Rules to clarify the problem. If yes, the seller should fill warranty card with offical stamp and send back to manufacturer. After repairing, manufacturer sends the product to the seller and the seller should inform the user to collect it. Freight arrangements please check with the shop you contact.

4. Quality Assurance Identification Rules
A. Quality Assurance is NOT applicable to those items: accessories like packing box, pouch, ear clip and earmuffs; product beyond warranty period; product got from unauthorized agents or informal channels; fake AWEI product; AWEI premium; arificial damaged product; external force damaged product.
B. Quality Assurance Identification Procedure: Check warranty period (by original invoice) —— confirm original product (check security code on AWEI offical website) —— check product damage (clarity artifical damage and external force like water, fire, chemicals or weight crush damages) —— check product quality (to confirm if the testing result is conform to description) ——check buying channel (subject to manufacturer's verification).

6

AWEI Warranty Card (please fill this carefully)

Model No.		Barcode	
User Name		TEL	
Address			
Seller		Seller Tel	
Seller Add			
Date of purchase		Date for Maintenance	
Damage situation		Maintenance time	
Remark			

备注：
1. 材质：128g铜版纸
2. 表面处理：无
3. 展开尺寸：900x100mm
4. 实际尺寸：100x100mm
5. 成型工艺：风琴折
6.印刷偏位：≤0.3 mm
7.符合ROHS标准

SELECT			V						
TOL / Dim	A	B	C	EPS	EPE	EPP	BAG	CTN	LABEL
0~6	0.05	0.05	0.10						0.20
6~30	0.10	0.15	0.20	0.50	0.50	0.50	3.00		0.20
30~120	0.15	0.20	0.30	0.50	0.50	0.50	5.00	1.00	0.25
120~300	0.20	0.30	0.40	1.00	1.00	1.00	10.00	1.00	0.30
300~450	0.25	0.40	0.50	2.00	2.00	2.00	15.00	2.00	0.50
450~600	0.30	0.50	0.60	3.00	3.00	3.00	20.00	3.00	0.80
DRAFT TOLERANCE			±0.20°		CRITICAL DIM MARK				*

SCALE 1:1
SHEET 1/1
UNIT mm

awei 深圳市雅乐电子有限公司

物料名称：KT18 户外k歌无线音箱 说明书

产品名称	料号	采购工程师	核准
KT18 户外K歌无线音箱		/	王海芳